

If you want modify default setting value. You can modify " reg.ini " file.
 Please refer reg.ini and this readme file.

For TouchKit driver 4.0.2 only.

Name	Value	Description
BeepMode	0x00000000 0x00000001 0x00000002	Off Beep Beep when touched Beep when released
BeepFrequency	0x00000064 ~0x00000FA0	Beep Frequency
BeepDuration	0x00000019 ~0x000001F4	Beep duration
MouseMode	0x80000000 0x40000000 0x20000000 0x10000000 0x00000000 0x00000001 0x00000002 0x00000003 0x00000004	make driver to report right button. enable auto right button feature. disable driver to report mouse event. Set this flag to make driver to bypass the software filter to get more fast response. Default value of mouse emulation mode. set the mouse emulation mode to be "Click on Touch". set the mouse emulation mode to be "Click on Release". set the mouse emulation mode to be "Click On Touch No Move". set the mouse emulation mode to be "click On Release No Move".
ConstDuration	0x00000000 ~0x00000078 (0 ~ 120)	constant touch parameter which define the touch duration in milli-second for auto right click.(3Sec = 120 * 0.025)
ConstRange	0x00000020 ~0x000008C0	constant touch parameter which define the touch range for auto right click. (1 pixel = 0x00000020 >> 5)

Edge compensation parameter

Name	Default value	Description
ILeft	110	ILeft Edge compensation parameter in left side.
IRight	110	IRight Edge compensation parameter in right side.
ITop	110	ITop Edge compensation parameter in upper side
IBottom	110	IBottom Edge compensation parameter in bottom side
IOffsetX	0	IOffsetX Offset parameter in X direction.
IOffsetY	0	IOffsetY Offset parameter in Y direction.
ulMode	0x00000001	ulMode Flag to enable/disable edge compensation. This flag must be either 0 or 1

Calibration Information data

Name	Defualt value	Description
ILLX	102	calibration parameter in X direction at lower left corner.
ILLY	102	calibration parameter in Y direction at lower left corner.
ILRX	1945	calibration parameter in X direction at lower

		right corner.
ILRY	102	calibration parameter in Y direction at lower right corner.
IURX	1945	calibration parameter in X direction at upper right corner.
IURY	1945	calibration parameter in Y direction at upper right corner.
IULX	102	calibration parameter in X direction at upper left corner.
IULY	1945	calibration parameter in Y direction at upper left corner.