


AIRBAG CONTROL MODULE I/O SIGNAL

AIRBAG SYSTEM (DIAGNOSTICS)

5. Airbag Control Module I/O Signal



A: WIRING DIAGRAM



AB-00617

AIRBAG CONTROL MODULE I/O SIGNAL


AIRBAG SYSTEM (DIAGNOSTICS)



AB-00618

AIRBAG CONTROL MODULE I/O SIGNAL

AIRBAG SYSTEM (DIAGNOSTICS)




(YELLOW) AB9 AB19 (YELLOW)

(YELLOW) AB11 AB20 (YELLOW)




AB10 (YELLOW)


AB12 (YELLOW)



AB7 (YELLOW)



AB8 (YELLOW)



AB-00134