

## 16.Rear Window Defogger System

### A: WIRING DIAGRAM

#### 1. REAR WINDOW DEFOGGER

<Ref. to WI-132, WIRING DIAGRAM, Rear Window Defogger System.>

### B: INSPECTION

Symptom	Repair order
Rear window defogger does not operate.	(1) Fuse (M/B No. 1) (F/B No. 17) (2) Rear defogger relay (3) Rear defogger timer (4) Defogger switch (5) Rear defogger condenser (6) Defogger wire (7) Wiring harness